

## Set up logo


For this step you need your own computer and a USB stick.

### STEP 1

On your computer:

- On the USB stick, create a folder and call it 'logos'
- Place your logo in PNG format in this folder
- Preferred size between 500 and 1000 pixels\*

*\*A smaller size is possible, but will have consequences for the quality of the printed logo on the ribbons*



### STEP 2

On the ribbontablet:

- Insert the USB stick in the hub
- Open the configuration screen of the app
- Go to LOAD and choose 'read data from USB'
- Slide the bar to the adjust to the preferred black/white version of your logo
- Return to the configuration screen
- Click GENERAL and choose 'Set logo'. Select your logo here.

After setting this, your logo will be printed on every ribbon!

